



|     |                     |     |     |                           |     |
|-----|---------------------|-----|-----|---------------------------|-----|
| 21  | Power Switch        | 1   | 38  | Filter                    | 1   |
| 20  | Electric Box        | 1   | 37  | Heating Element Support   | 1   |
| 17  | Microswitch         | 1   | 36  | Heating Element           | 1   |
| 16  | Terminal            | 1   | 35  | Support                   | 2   |
| 15  | Cable Lock          | 1   | 34  | Clamp 2                   | 4   |
| 14  | Relay               | 1   | 33  | Thermostat                | 1   |
| 13  | Security Thermostat | 1   | 32  | Clamp 1                   | 2   |
| 12  | Handle for Cover    | 1   | 31  | Oil Indicator             | 1   |
| 11  | Cover               | 1   | 30  | Pothook For Frying Basket | 1   |
| 8   | Oil level Pip       | 1   | 29  | Turning Axis              | 4   |
| 7   | Handle for Basket   | 1   | 27  | Heating Indicator Light   | 1   |
| 6   | Frying Basket       | 1   | 26  | Power Indicator Light     | 1   |
| 5   | Valve               | 1   | 25  | Base of the Knob          | 1   |
| 3   | Gasket              | 1   | 24  | Knob                      | 1   |
| 2   | Body                | 1   | 23  | PVC                       | 1   |
| 1   | Plastic Leg         | 4   | 22  | Electric Box Cover        | 1   |
| NO. | Name                | QTY | NO. | Name                      | QTY |