

# Sealing Machine

## User Manual

- ii. Don't use the wet article to clean the sealing platform.
- iii. Should the bottom cloth be worn, it will make this machine into short way and to damage the heating element. So every time in replacing the heating element, check the bottom cloth, replace it by a new bottom cloth if the old one is worn.
- iv. During it is necessary to replete a new thermo-electric wire, don't use any specification other than equivalent with the original.
- v. After a very long time usage, please check the handle rubber. The worn of hand rubber will influence the sealing effect, please

## V. SPECIFICATION


MODEL		TT-Z16A	TT-Z17A	TT-Z18A	TT-Z19A
Voltage		220/110V	220/110V	220/110V	220/110V
Power		150W	300W	400W	800W
Sealing length		100mm	200mm	300mm	400mm
Sealing thickness		0.2-1.5(sec)	0.2-1.5(sec)	0.2-1.5(sec)	0.2-1.5(sec)
Weight		21/kg/20pcs	17/kg/10pcs	19/kg/10pcs	27/kg/5pcs
Dimensions		49x48x34cm	52x35x38cm	50x45x38cm	59x57x20cm

TT-Z16/17/18/19 SERIES

## PASTIC FILM SEALER

Standard model:

TT-Z16/17/18/19



OPERATION INSTRUCTION  
ISO9001:2000 CE

## I.DESCRPTION OF MAIN PARTS

Picture:

time duration, putting one plastic bag on the sealing platform, and then push down the handle. The electronic circuit controls the heat time automatically, the light turns off (to cut off the power automatically ). After 1-2 seconds, release the handle. The perfect seal is complete.

ii.In case of the break or damage appear on the seal. It because of the over long heat time. Please regulating the heat time toward the directions for shorting it.

iii.Non-tighten seal is because of the too short heat time, please regulating it toward to directions for longer.

iv.Should the plastic bag sticks to the handle rubber or to be pulled. It is because of the cooling time is not enough. The cooling time have to get longer after the light turns off (please keep the handle down for a short time).

v.After regulating the heat time duration, it will keep unchanged for every usage.it is unnecessary to make any regulating for the continuous sealing. But the second action of sealing have to be continued after the off of indicator light, and the return of platen arm.

vi.Please plugs the AC cord into the socket always, it will not consume the power at all during not in use condition.

## II.PURPOSE

The TT-Z series plastic film sealer is the perfect sealer for PE and PP bags ,  
to package various kinds of candy food staff, general merchandises, stationery, drugs, etc.

## III.OPERATION

i.This machine doesn't use the power switch, plug the accord into socket, according to the thickness of the material to be sealer. Begulating the heat

## IV.NOTES

i.Always keep the sealing platform clean, avoiding the oxidization of the residual on that platform which will reduce the life of the heating element and of the heat-resist cloth.